

Eagle Plus

EPA Water Sense

Settings and parts used during qualification testing

Program 1

- \* Zone #1 = 12 min.
- \* Start time = 0100
- \* Skip days = 0 (Water everyday)

Program 2

- \* Zone #2 = 7 min.
- \* Start times = 0130, 0230
- \* Skip days = 0 (Water everyday)

Program 3

- \* Zone #3 = 16 min.
- \* Start time = 0300
- \* Skip days = 1

Program 4

- \* Zone #4 = 14 min.
- \* Start time = 0330
- \* Skip days = 1

Program 5

- \* Zone #5 = 21 min.
- \* Zone #6 = 15 min.
- \* Start times = 0400, 0600, 0800
- \* Skip days = 0 (Water everyday)

Other items used

- \* Toro rain sensor, model TWRS
- \* [www.icentralirrigation.com](http://www.icentralirrigation.com), utilizing "ZipET" for daily ET source  
Zip code = 80112